

2

AD

AD-A220 641

TECHNICAL REPORT ARCCB-TR-89022

**DETERMINATION OF CHROMIC ACID IN  
CHROMIUM PLATING SOLUTIONS USING  
A REDOX TITRATION AND INDICATOR**

**SAMUEL SOPOK**

**AUGUST 1989**

**SDTIC**  
**ELECTE**  
**APR 12 1990**  
**B**  
**D**



**US ARMY ARMAMENT RESEARCH,  
DEVELOPMENT AND ENGINEERING CENTER  
CLOSE COMBAT ARMAMENTS CENTER  
BENÉT LABORATORIES  
WATERVLIET, N.Y. 12189-4050**



**APPROVED FOR PUBLIC RELEASE; DISTRIBUTION UNLIMITED**

90 04 01-6

#### DISCLAIMER

The findings in this report are not to be construed as an official Department of the Army position unless so designated by other authorized documents.

The use of trade name(s) and/or manufacturer(s) does not constitute an official indorsement or approval.

#### DESTRUCTION NOTICE

For classified documents, follow the procedures in DoD 5200.22-M, Industrial Security Manual, Section II-19 or DoD 5200.1-R, Information Security Program Regulation, Chapter IX.

For unclassified, limited documents, destroy by any method that will prevent disclosure of contents or reconstruction of the document.

For unclassified, unlimited documents, destroy when the report is no longer needed. Do not return it to the originator.

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM
1. REPORT NUMBER ARCCB-TR-89022	2. GOVT ACCESSION NO.	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle)  DETERMINATION OF CHROMIC ACID IN CHROMIUM PLATING SOLUTIONS USING A REDOX TITRATION AND INDICATOR		5. TYPE OF REPORT & PERIOD COVERED  Final
		6. PERFORMING ORG. REPORT NUMBER
7. AUTHOR(s)  Samuel Sopok		8. CONTRACT OR GRANT NUMBER(s)
9. PERFORMING ORGANIZATION NAME AND ADDRESS U.S. Army ARDEC Benet Laboratories, SMCAR-CCB-TL Watervliet, NY 12189-4050		10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS AMCMS No. 6126.23.1BLO.0 PRON No. 1A92ZNACNMSC
11. CONTROLLING OFFICE NAME AND ADDRESS U.S. Army ARDEC Close Combat Armaments Center Picatinny Arsenal, NJ 07806-5000		12. REPORT DATE August 1989
		13. NUMBER OF PAGES 11
14. MONITORING AGENCY NAME & ADDRESS (If different from Controlling Office)		15. SECURITY CLASS. (of this report)  UNCLASSIFIED
		15a. DECLASSIFICATION/DOWNGRADING SCHEDULE
16. DISTRIBUTION STATEMENT (of this Report)  Approved for public release; distribution unlimited.		
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)		
18. SUPPLEMENTARY NOTES  Submitted to <u>Plating and Surface Finishing</u> .		
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) Chemical Analysis Chromic Acid Chromium Plating Solutions Redox Titration Redox Indicator,		
20. ABSTRACT (Continue on reverse side if necessary and identify by block number)  The chemical literature lacks a simple analytical method for adequately controlling chromic acid in chromium plating solutions during the plating process. In this report, a simple method for analyzing and controlling chromic acid during the plating process is presented. The optimum operating range of chromic acid is 240 to 260 g/l and the resulting precisions are in the range of 0 to 2.5 g/l, providing adequate control of these plating solutions supported by five years of testing.		

# TABLE OF CONTENTS

	<u>Page</u>
ACKNOWLEDGMENTS .....	ii
INTRODUCTION .....	1
EXPERIMENTAL PROCEDURE .....	2
RESULTS AND DISCUSSION .....	3
REFERENCES .....	5

## TABLES

I. EXPERIMENTAL REDOX TITRATION DATA FOR THE POTASSIUM DICHROMATE STANDARD SOLUTION .....	6
II. EXPERIMENTAL REDOX TITRATION DATA FOR THE CHROMIC ACID SAMPLE SOLUTIONS .....	6
III. PRECISION OF A 25-ml CLASS-A PIPET .....	7
IV. PRECISION OF A 10-ml CLASS-A PIPET .....	7
V. PRECISION OF A 500-ml CLASS-A VOLUMETRIC FLASK .....	8
VI. PRECISION OF A 50-ml CLASS-A BURET .....	8
VII. PRECISION OF A 4.90-g/l POTASSIUM DICHROMATE STANDARD SOLUTION BY TITRATION .....	9

Accession For	
NTIS GRA&I	<input checked="" type="checkbox"/>
DTIC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By	
Distribution/	
Availability Codes	
Dist	Avail and/or Special
A-1	

## ACKNOWLEDGMENTS

Special thanks are given to Ellen Fogarty and Rose Neifeld of Benet Laboratories for their respective word processing and technical editing work on this manuscript.

## INTRODUCTION

The chemical literature lacks a simple analytical method for adequately controlling chromic acid in chromium plating solutions during the plating process. Lack of optimization of these plating solutions causes serious problems for the chromium plating industry such as poor quality products, wasted human resources, and wasted electrical energy.

A quick general analytical method to determine chromic acid in chromium plating solutions is to use a Baume hydrometer and to assume that all of the dissolved material is chromic acid (ref 1). However, the problem with this density method is that it not only measures chromic acid, but all dissolved material and must be corrected for temperature. It is not uncommon for this method to deliver relative precisions in the range of 5 to 10 percent for these chromic acid measurements.

Another chemical analysis method to determine chromic acid in chromium plating solutions is to use atomic absorption or inductively coupled plasma spectrometry and to assume that all chromium is in the form of chromic acid (ref 2). The problem with this method is that Cr(III) ions are also present in these solutions and must be corrected by a separate Cr(III) ion analysis method. Relative precisions of the combined methods are in the range of 3 to 5 percent.

Still another chemical analysis method to determine chromic acid in chromium plating solutions is sodium thiosulfate titration using a potassium iodide/starch indicator (refs 3-5). This method is time-consuming since the sodium thiosulfate is unstable and must be standardized every time it is used, although after standardization relative precisions are in the range of 1 to 2 percent.

---

References are listed at the end of this report.

The simple method given in this report provides both acceptable analysis and control of chromic acid in chromium plating solutions. The method uses a ferrous ammonium sulfate redox titrant and redox indicator. General background on redox titration is extensive (refs 2-6).

## EXPERIMENTAL PROCEDURE

Strict analytical chemistry methods and procedures are followed throughout this experimental procedure section. An excellent source of reference for these methods and procedures is by Fritz and Schenk (ref 6).

One analytical reagent grade standard solution is required. This solution is a  $4.90 \pm 0.01$ -g/l potassium dichromate solution that meets American Chemical Society (ACS) Standards and Federal Specification O-C-303D for hexavalent chromium (refs 7-8).

Two other reagent grade solutions are required. The first of these is the redox titrant which has  $45.0 \pm 0.01$  grams of ferrous ammonium sulfate (six hydrate) and  $60 \pm 1$  milliliters (ml) of sulfuric acid per liter of total solution. The second is the redox indicator which is a  $10.0 \pm 0.1$ -g/l sodium diphenylamine sulfonate solution.


Preparation of a potassium dichromate standard for redox titration analysis requires that 25 ml of the analytical reagent grade standard solution prepared above is diluted to about the 200-ml mark with deionized water in a 400-ml beaker. In addition, 5 ml of concentrated sulfuric acid, 5 ml of concentrated phosphoric acid, a stirring bar, and five drops of the redox indicator are added to the beaker. The redox titrant is titrated to a green endpoint recording the amount of titrant dispensed.

Preparation of a chromium plating solution sample for redox titration analysis requires that 10 ml of the sample solution is pipetted into a 500-ml volumetric flask which is filled to the mark with deionized water. Then 25 ml of the diluted sample solution in the flask is diluted to about the 200-ml mark with deionized water in a 400-ml beaker. As before, 5 ml of concentrated sulfuric acid, 5 ml of concentrated phosphoric acid, a stirring bar, and five drops of the redox indicator are added to the beaker. The redox titrant is titrated to a green endpoint recording the amount of titrant dispensed.

All standard and sample solutions are analyzed in triplicate. Chromic acid concentrations in the samples are calculated by simple proportion.

## RESULTS AND DISCUSSION

Experimental redox titration data are presented in Table I for the potassium dichromate standard solution and in Table II for the chromic acid sample solutions one and two. The redox titration consists of the following:





All hexavalent chromium is in the dichromate form due to the addition of sulfuric and phosphoric acids added to the standard and sample solutions above.

Theoretically, from Eq. (1), it is calculated that a 21.77-ml volume of the titrant at the endpoint is required for the standard solution which is the value experimentally obtained in Table I.

Although all standards and samples are analyzed in their dichromate form, all samples are actually in the chromate form and are reported as chromium trioxide using the following equations for conversion:





From Eqs. (2) and (3), it is found that the sodium dichromate standard solution has the equivalent of 245 g/l potassium dichromate or 166.55 g/l chromium trioxide ( $\text{CrO}_3$ ).

Therefore, by simple proportion, the calculation for determining the concentration of chromium trioxide in the sample solutions is:

$$\text{g/l CrO}_3 = (166.55) (\text{titrant ratio}) \quad (4)$$

where the titrant ratio is the milliliter of sample titrant used divided by the milliliter of standard titrant used.

From Eq. (4), the values of 244.2 and 255.5 g/l chromium trioxide are respectively calculated for sample solutions one and two for the data given in Table II.

It is useful to evaluate the variations in precision for the materials and methods used. Tables III through VII present these data for the 25-ml class-A pipets, 10-ml class-A pipets, 500-ml class-A volumetric flasks, 50-ml class-A burets, and the 4.90-g/l potassium dichromate standard solution, respectively.

The data obtained by this method are sufficient to adequately control the chromic acid in the Watervliet Arsenal's chromium plating processes according to its standard operating procedures (ref 9), thus providing efficient use of resources. The optimum operating range of chromic acid is 240 to 260 g/l and the resulting precisions are in the range of 0 to 2.5 g/l, providing adequate control of these plating solutions supported by five years of testing.

## REFERENCES

1. Metal Finishing Guidebook, Metals and Plastics Publications, Inc., Hackensack, NJ, 1984.
2. H. Bauer, G. Christian, and J. O'Reilly, Instrumental Analysis, Allyn and Bacon, Inc., Boston, MA, 1978.
3. D. Peters, J. Hayes, and G. Hieftje, Chemical Separations and Measurements: Theory and Practice of Analytical Chemistry, W. B. Saunders Company, Philadelphia, PA, 1974.
4. K. Langford and J. Parker, Analysis of Electroplating and Related Solutions, Metals and Plastics Publications, Inc., Hackensack, NJ, 1986.
5. T. Irvine, The Chemical Analysis of Electroplating Solutions: A Theoretical Approach, Chemical Publishing Company, New York, 1970.
6. J. Fritz and G. Schenk, Quantitative Analytical Chemistry, Fifth Edition, Allyn and Bacon, Inc., Boston, MA, 1987.
7. "Chromium Trioxide Specification," American Chemical Society, Washington, DC, 1982.
8. "Chromium Trioxide," Federal Specification O-C-303D, General Services Administration, Washington, D.C., 1986.
9. "Chromium Plating Procedure (120-mm M256)," Drawing #12520710, Code #19206, Watervliet Arsenal, Watervliet, NY, 1980.

TABLE I. EXPERIMENTAL REDOX TITRATION DATA FOR THE  
- POTASSIUM DICHROMATE STANDARD SOLUTION

Replicate	Titrant Used (ml)
1	21.80
2	21.75
3	21.75
X(avg)	21.77

TABLE II. EXPERIMENTAL REDOX TITRATION DATA FOR  
THE CHROMIC ACID SAMPLE SOLUTIONS

Replicate	Sample One Titrant Used (ml)	Sample Two Titrant Used (ml)
1	31.95	33.40
2	31.90	33.40
3	31.90	33.40
X(avg)	31.92	33.40

TABLE III. PRECISION OF A 25-ml CLASS-A PIPET

Replicate	Volume (ml)*
1	25.04
2	24.99
3	24.96
4	25.03
5	25.01
6	25.05
X(avg)	25.01
Sn	0.03

TABLE IV. PRECISION OF A 10-ml CLASS-A PIPET

Replicate	Volume (ml)*
1	10.03
2	10.00
3	9.98
4	9.99
5	9.98
6	10.04
X(avg)	10.00
Sn	0.02

\*Volumes are calculated from the weight-volume relationship of a pipetted deionized water solution corrected for temperature.

TABLE V. PRECISION OF A 500-ml CLASS-A VOLUMETRIC FLASK

Replicate	Volume (ml)*
1	500.6
2	500.1
3	499.8
4	500.0
5	500.5
6	499.3
X(avg)	500.1
Sn	0.4

TABLE VI. PRECISION OF A 50-ml CLASS-A BURET

Replicate	Volume (ml)*
1	24.94
2	24.98
3	25.02
4	25.05
5	24.98
6	25.05
X(avg)	25.00
Sn	0.04

\*Volumes are calculated from the weight-volume relationship of a contained deionized water solution corrected for temperature.

TABLE VII. PRECISION OF A 4.90-g/l POTASSIUM DICHROMATE  
STANDARD SOLUTION BY TITRATION

Replicate	K <sub>2</sub> Cr <sub>2</sub> O <sub>7</sub> Conc. (g/l)*
1	4.91
2	4.88
3	4.90
4	4.89
5	4.91
6	4.91
X(avg)	4.90
Sn	0.01

\*Potassium dichromate as chromic acid concentrations are calculated using Federal Specification O-C-303D which is a standard chemical analysis method for chromic acid.

# TECHNICAL REPORT INTERNAL DISTRIBUTION LIST

	NO. OF COPIES
CHIEF, DEVELOPMENT ENGINEERING DIVISION	
ATTN: SMCAR-CCB-D	1
-DA	1
-DC	1
-DM	1
-DP	1
-DR	1
-DS (SYSTEMS)	1
CHIEF, ENGINEERING SUPPORT DIVISION	
ATTN: SMCAR-CCB-S	1
-SE	1
CHIEF, RESEARCH DIVISION	
ATTN: SMCAR-CCB-R	2
-RA	1
-RM	1
-RP	1
-RT	1
TECHNICAL LIBRARY	5
ATTN: SMCAR-CCB-TL	
TECHNICAL PUBLICATIONS & EDITING SECTION	3
ATTN: SMCAR-CCB-TL	
DIRECTOR, OPERATIONS DIRECTORATE	1
ATTN: SMCWV-OD	
DIRECTOR, PROCUREMENT DIRECTORATE	1
ATTN: SMCWV-PP	
DIRECTOR, PRODUCT ASSURANCE DIRECTORATE	1
ATTN: SMCWV-QA	

NOTE: PLEASE NOTIFY DIRECTOR, BENET LABORATORIES, ATTN: SMCAR-CCB-TL, OF ANY ADDRESS CHANGES.

# TECHNICAL REPORT EXTERNAL DISTRIBUTION LIST

	<u>NO. OF COPIES</u>		<u>NO. OF COPIES</u>
ASST SEC OF THE ARMY RESEARCH AND DEVELOPMENT ATTN: DEPT FOR SCI AND TECH THE PENTAGON WASHINGTON, D.C. 20310-0103	1	COMMANDER ROCK ISLAND ARSENAL ATTN: SMCRI-ENM ROCK ISLAND, IL 61299-5000	1
ADMINISTRATOR DEFENSE TECHNICAL INFO CENTER ATTN: DTIC-FDAC CAMERON STATION ALEXANDRIA, VA 22304-6145	12	DIRECTOR US ARMY INDUSTRIAL BASE ENGR ACTV ATTN: AMXIB-P ROCK ISLAND, IL 61299-7260	1
COMMANDER US ARMY ARDEC ATTN: SMCAR-AEE	1	COMMANDER US ARMY TANK-AUTMV R&D COMMAND ATTN: AMSTA-DDL (TECH LIB) WARREN, MI 48397-5000	1
SMCAR-AES, BLDG. 321	1	COMMANDER US MILITARY ACADEMY	1
SMCAR-AET-O, BLDG. 351N	1	ATTN: DEPARTMENT OF MECHANICS WEST POINT, NY 10996-1792	
SMCAR-CC	1		
SMCAR-CCP-A	1	US ARMY MISSILE COMMAND	
SMCAR-FSA	1	REDSTONE SCIENTIFIC INFO CTR	2
SMCAR-FSM-E	1	ATTN: DOCUMENTS SECT, BLDG. 4484	
SMCAR-FSS-D, BLDG. 94	1	REDSTONE ARSENAL, AL 35898-5241	
SMCAR-IMI-I (STINFO) BLDG. 59	2		
PICATINNY ARSENAL, NJ 07806-5000			
DIRECTOR US ARMY BALLISTIC RESEARCH LABORATORY ATTN: SLCBR-DD-T, BLDG. 305	1	COMMANDER US ARMY FGN SCIENCE AND TECH CTR ATTN: DRXST-SD	1
ABERDEEN PROVING GROUND, MD 21005-5066		220 7TH STREET, N.E. CHARLOTTESVILLE, VA 22901	
DIRECTOR US ARMY MATERIEL SYSTEMS ANALYSIS ACTV ATTN: AMXSY-MP	1	COMMANDER US ARMY LABCOM	
ABERDEEN PROVING GROUND, MD 21005-5071		MATERIALS TECHNOLOGY LAB ATTN: SLCMT-IML (TECH LIB)	2
COMMANDER HQ, AMCCOM		WATERTOWN, MA 02172-0001	
ATTN: AMSMC-IMP-L	1		
ROCK ISLAND, IL 61299-6000			

NOTE: PLEASE NOTIFY COMMANDER, ARMAMENT RESEARCH, DEVELOPMENT, AND ENGINEERING CENTER, US ARMY AMCCOM, ATTN: BENET LABORATORIES, SMCAR-CCB-TL, WATERVLIET, NY 12189-4050, OF ANY ADDRESS CHANGES.



# TECHNICAL REPORT EXTERNAL DISTRIBUTION LIST (CONT'D)

	<u>NO. OF COPIES</u>		<u>NO. OF COPIES</u>
COMMANDER US ARMY LABCOM, ISA ATTN: SLCIS-IM-TL 2800 POWDER MILL ROAD ADELPHI, MD 20783-1145	1	COMMANDER AIR FORCE ARMAMENT LABORATORY ATTN: AFATL/MN EGLIN AFB, FL 32542-5434	1
COMMANDER US ARMY RESEARCH OFFICE ATTN: CHIEF, IPO P.O. BOX 12211 RESEARCH TRIANGLE PARK, NC 27709-2211	1	COMMANDER AIR FORCE ARMAMENT LABORATORY ATTN: AFATL/MNF EGLIN AFB, FL 32542-5434	1
DIRECTOR US NAVAL RESEARCH LAB ATTN: MATERIALS SCI & TECH DIVISION CODE 26-27 (DOC LIB) WASHINGTON, D.C. 20375	1 1	METALS AND CERAMICS INFO CTR BATTELLE COLUMBUS DIVISION 505 KING AVENUE COLUMBUS, OH 43201-2693	1

NOTE: PLEASE NOTIFY COMMANDER, ARMAMENT RESEARCH, DEVELOPMENT, AND ENGINEERING CENTER, US ARMY AMCCOM, ATTN: BENET LABORATORIES, SMCAR-CCB-TL, WATERVLIET, NY 12189-4050, OF ANY ADDRESS CHANGES.